


DUCTCAP®




Ductcap® Cover Specification Sheet


The Ductcap cover is designed to protect the entire air handling system during construction. Using a Ductcap cover on all unfinished ends, helps prevent moisture, dirt particles, dust and debris from entering the air handling system. The reusable Ductcap cover is designed to be installed by stretching the elastic band over the round branch or any other open end. No tape, screws or nylon ties are needed to secure the Ductcap cover to the duct.




#0610 - 16" x 14" DUCTCAP fits 6" through 9" round or 16-31 linear inches
#1014 - 24" x 14" DUCTCAP fits 10" through 14" round or 32-47 linear Inches



16" or 24" are manufactured from .002 mil thickness orange polypropylene plastic with a 1/4" elastic band



#1418 - 30" x 18" DUCTCAP fits 14" through 18" round or 48-59 linear inches
#1824 - 40" x 18" DUCTCAP fits 18" through 24" round or 60-79 linear inches
#2430 - 50" x 18" DUCTCAP fits 24" through 30" round or 80-99 linear inches
#3038 - 60" x 24" DUCTCAP fits 30" through 38" round or 100-119 linear inches



30", 40", or 60" are manufactured from .0025 mil thickness orange polypropylene plastic with a 3/8" elastic band.

Americover®

2067 Wineridge Place, Ste. F • Escondido, CA 92029
800-747-6095 • 760-747-6095 • fax 760-747-1920
www.americover.com